

# Open/Eject CD: Mac OSX

---

## How do I Open/Eject the CD on a Mac?

---

To use the CD/DVD player on a Mac computer press the CD/DVD open and eject button located on the top right hand side of the keyboard.

